



Make sure shower drain is no more than 3" under the top of the concrete to the top of the 2" pipe. We are getting the drains too high, allow pitch so that drain is under concrete at least 3"

ATTENTION ALEX !!! - THIS HOUSE GETS A SOFTENER LOOP - RUN BIBS ON SEPARATE LINE BACK TO THE HEATER AREA

ALL MEASUREMENT ARE TAKEN FROM OUTSIDE OF RIM WALL

2 story home, dont forget stack and water by garage for 2nd floor