



ALL MEASUREMENT ARE TAKEN FROM OUTSIDE OF RIM WALL

Make sure shower drain are no more than 3" under the top of the concrete to the top of the 2" pipe. Master and Hall bath get curbless showers
We are getting the drains too high , allow pitch so that drain is under concrete at least 3"