
Redwood Miamisburg North Springboro Pike OH P1
Construction Site Plan



# **BUILDING M**

- 1 Meadowood Left
- 1 Forestwood Right
- 1 Forestwood Left
- 1 Meadowood Right



# **GENERAL NOTES:**

- 1. REFER TO ENLARGED FLOOR PLANS FOR INTERIOR ROOM DIMENSIONS AND OTHER SPECIFIC INFORMATION.
- 2. SEE SHEET SERIES A6.X FOR DOOR AND WINDOW SCHEDULES.
- 3. CONTRACTOR SHALL PROVIDE ALL WALL BOXES, ETC. AS REQUIRED FOR ROUGH-IN CONDITIONS. TELEPHONE AND T.V. PREWIRE TO BE COMPLETED BEFORE INSTALLATION OF GYPSUM WALLBOARD.
- 4. ALL GRAB BAR BLOCKING FOR FUTURE GRAB BARS AT HANDICAP BATHS MUST BE ABLE TO RESIST A FULL FORCE OF 250 LBS. EXERTED AT ANY POINT IN ANY DIRECTION ON FUTURE GRAB BARS. BLOCKING AT TUBS AND SHOWERS IS TO BE FACTORY INSTALLED.
- 5. ALL DIMENSIONS ARE TO FACE OF STUD UNLESS OTHERWISE NOTED.
- 6. FOR INTERIOR FINISHES FOR WALLS AND CEILINGS REFER TO FLAME AND SMOKE INDEX
- 7. PRIMARY ENTRY DOORS SHALL HAVE "0" CLEARANCE THRESHOLDS TO MEET ALL ANSI
- 8. ALL EXPOSED EXTERIOR WOOD SHALL BE PRESSURE TREATED. SEE FRAMING PLANS & WALL SECTIONS FOR MORE INFORMATION.

## NOTES:

- 1. ALL SINGLE STORY UNITS MUST MEET FAIR HOUSING ACT ACCESSIBILITY GUIDELINES FOR
- 2. ALL UNITS ARE TYPE 'B' DWELLING UNITS AS PER ANSI A117.1-2009, SECTION 1004.

### NOTES:

REFER TO ENLARGED FLOOR PLAN SHEETS TO SEE CORRESPONDING PLANS FOR LABELED

### NOTE:


STAGGER ADJACENT A/C UNITS TO PROVIDE FOR SUFFICIENT ACCESS AROUND EACH.



**REVISIONS** 

330.666.5770 330.666.8812

A2.28 59 OF 137



# NOTES: MUST install tub boxes for tub and shower traps!! Wait until gravel prepped 28' Run trunk line for sewer at 31' from rear of unit 10" Lave 11-6 1/2" Toilet 1-6 1/2" Toilet 5-7" Floor Drain Shower 1-3'-4"

Clean Out  $\bar{n}$ 

-10'-10"

Washer 👆


1'-8 1/2"





**GARAGE ON THIS SIDE OF BUILDING** 


**Kicthen** 

\*\* ONLY GOES IN ONE UNIT 3" Floor Drain for Backflow











**Meadowood Right WATER** 



**GARAGE ON THIS SIDE OF BUILDING** 

NOTES:

MUST install tub boxes for tub and shower traps!! Wait until gravel prepped



**Forestwood Left PVC**