



NATE !!
 Run 3" to base and stub up 2" pipe
 This pipe must be as tight to front foundation wall as possible
 remove insulation and make sure pipe in tight coming up wall