MAKE SURE SUMP INSTALLED
ALL PVC LINES ASIDE OF ONE
2" RISER CAPPED OFF !!

DOUBLE CHECK BATH AND BAR
MEASUREMENTS WHEN DONE SO
THEY ARE EXACT OR CLOSE TO IT

19'-6 3/4"

19'-11"

20'-9"

7'-3"

6'

1'-8"

2" Wet Bar

Lav

Tub

Toilet

4'-5"

5'

Floor Drain
BWV tight to F.D.

3" Stack

8'

9'

BWV FOR
BATHROOM AND
WET BAR , CHECK
OUT PRINTS AND
PLACE IN
UNFINISHED AREA

VK 9

3" SEWERS
4X2 FLOOR DRAIN
BACKWATER VALVES REQUIRED
FINISHED BASEMENT AND BATH
WET BAR IN BASEMENT
RADON VENT !!

GARAGE

3" Stack

12'

3" Radon ,
put next to
sump pit

SEWER